



TECH CARE VOLUME CHAMBERS SET UP SHEET

Thanks for purchasing Tech-Care's quick release volume chambers. Set up is as followed:

- *Remove the air bleed screws from the top of the fork cap. (Retain for future use, don't throw out.)
- *Screw in the quick connect elbow into the air bleeder thread (Not to over tighten), tighten with screw driver torque only, putting the elbow at 45 degree angle inwards. All KYB, and SHOWA forks use 5mm threads (BLACK ELBOW), OHLINS, and WP forks use 4mm threads (WHITE ELBOW).
- *Install your volume chambers to your forks using TECH-CARE volume chamber holders.
- *Criss cross the lines while being careful not to pinch the line. Make sure you put the lines behind all of your control lines. It's best to put the volume chamber lines closest to the top clamp.
- *Turn the chamber compression adjuster to the indicated amount.
(Make sure they are completely closed, turn counter-clockwise three turns (standard setting).